

WARING PRO™

WINE AERATOR



WA100


For your safety and continued enjoyment of this product,
always read the instruction book carefully before using.

IMPORTANT SAFEGUARDS

Handle wine aerator with care. Keep in a safe place where it will not be knocked over or dropped.

PARTS

1. Wine Aerator
2. Filter
3. Stand
4. Base



PRODUCT FEATURES

The Waring Pro™ Wine Aerator combines innovation with cutting-edge design. Aeration enriches the flavor and bouquet of young tannic red wines, and white wines as well. It produces a softer, silky smooth feel.

OPERATING INSTRUCTIONS

Rinse the aerator, stand and base before each use.

1. Place the stand on top of a wine glass, with the raised side facing down into the glass (fig. 1).
2. Place the aerator in the stand, making sure it is securely in place (fig. 2). (For a more secure system, one hand may be used to hold the aerator while the other pours the wine.)
3. Pour the wine into the aerator slowly (fig. 3).
4. You will hear the aerator draw in and mix the proper amount of air as it filters into the wine glass, allowing the wine to breathe instantly.
5. Repeat the above process for additional glasses of wine. Be sure to clean the aerator if you wish to switch to a different type of wine.
6. When finished, take the aerator out of the stand and clean it according to the instructions listed in the Cleaning and Maintenance section. Store the aerator and stand on the base provided (fig. 4).



fig. 1



fig. 2



fig. 3



fig. 4

HELPFUL HINTS

- The aerator is for use with red or white wine. Do not use for any other liquid and do not use as a funnel.
- Wash the aerator after each use.

CLEANING AND MAINTENANCE

To disassemble the wine aerator, twist the upper container away from the brushed stainless steel center. Lower filter housing is removable as well. Be sure to reassemble properly before use.

Always rinse the aerator, stand and base after each use. **HAND WASH ONLY** with clean water and do not use abrasive cleansers, as they might damage the unit. Dry thoroughly before storing.

DO NOT WASH ANY PART OF THIS AERATOR IN A DISHWASHER.

Any other servicing should be provided by an authorized service representative.

Trademarks or service marks of third parties used herein are
the trademarks or service marks of their respective owners.

©2012 Waring Consumer Products
150 Milford Road
East Windsor, NJ 08520
www.waringpro.com

Printed in China
WA100 IB
12WR128924

IB-11223